



USER INSTRUCTIONS
ELECTRIC FAN HEATER
WITH REMOTE CONTROL AND IONIZER
MODEL No. QE-7050A

Thank You very much for your custom

You have purchased one of the most modern and reliable electrical appliances currently available, which we know will give you long and reliable service.

As with all electrical appliances, it is important that all safeguards are followed. We therefore ask you to read through these instructions carefully and to keep them in a safe place for future reference.

This manual can be downloaded from the Quantum Ecoelec website at

www.quantum-ecoelec.com/support

THE CONTENTS OF THE BOX

Along with these instructions the box should also contain the following items

The most important item is a QE-7050A wall heater

1 off Remote control

2 off No8 Woodscrews, 35 mm long

2 off plastic Rawlplugs for fixing the heater to a concrete or brick wall

If there is anything missing please call 05602-045420 between 8:00am and 4:00pm Mon to Fri and we will do our best to replace the items as soon as possible, or you can email us at:-

support@quantum-ecoelec.com

CONFORMITY

This product is CE, TÜV & RoHS marked and conform to these standards.




Environmental Protection

European directive 2002/96/EC on waste electrical and electronic equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted household waste.

Please recycle where facilities exist. Check with your local Authority on recycling advice and disposal sites in your area.

INSTALLATION INSTRUCTIONS



ALL ELECTRICAL WORK SHOULD BE CARRIED OUT BY A COMPETENT ELECTRICIAN

- 1 Decide on a suitable location.
- 2 Mark the position for the 2 No.8 Woodscrews. (supplied)
- 3 Fit the screws leaving the screws protruding 15mm from the wall.
- 4 Mark the position on the wall for the 13A Fused Spur connection.
- 5 Install the fused spur back box and supply cable. (Surface mount or sunken)
- 6 Mount the heater on to the 2 off No.8 Woodscrews.
- 7 Ensure that the mains supply is turned off.
- 8 Connect the supply to the fused spur front plate.
- 9 Connect the unit to the front plate as described below.
- 10 Replace the front plate.
- 11 Installation is now complete.

CONNECTION DETAILS

THIS UNIT MUST BE CONNECTED TO THE MAINS SUPPLY BY A SWITCHED SPUR

The wires in the cable attached to this unit are coloured in accordance with the following code:-

BROWN	-----	LIVE
GREEN/YELLOW	-----	EARTH
BLUE	-----	NEUTRAL

THIS APPLIANCE MUST BE EARTHED

As the colours may not correspond with the markings identifying the terminals in the fused spur proceed as follows.

- Blue wire must be connected to the terminal marked 'N LOAD'
- Brown wire must be connected to the terminal marked 'L LOAD'
- Green/Yellow wire must be connected to the terminal 'E' or marked \perp

OPERATION

There may be a trace of smoke or odour during the first few minutes of initial use or when the unit has not been used for a period of time. This is quite normal and will quickly disappear.

FROM THE FRONT PANEL

To switch on the heater press the ON/OFF button on the front panel of the heater. This will switch the FAN on and open the vanes.

Pressing the ON/OFF again selects 1250W low heat setting.

By Pressing the ON/OFF button again the 2500W high heat setting will be selected.

Press again to turn vane swing ON.

Pressing the ON/OFF button again turns ON the IONIZER function.

Press again to turn the unit OFF.

The timer can be set from ½ hour to 7 ½ hours by pressing the TIMER button which steps up ½ hour with each press.

FROM THE REMOTE CONTROL

The remote control requires two AAA batteries. (not supplied)

To switch on the unit press the ON/OFF button on the remote control to switch on the FAN and open the vanes.

Pressing the HEATER button will select the low heat setting.

Press the HEATER button again to select the high heat setting.

The ambient temperature of the room can be selected from 18C to 40C by pressing the UP or DOWN to select the required temperature.

The timer can be set from ½ hour to 7 ½ hours by pressing the TIMER button which steps up ½ hour with each press.

Press the swing button to start the vane swinging.

To turn off the unit press the ON/OFF button.

IONIZER

The ionizer will neutralize any airborne pollutants (pollen etc..) To turn on the IONIZER press the IONIZER button.

ATTENTION. When the unit is switched off the unit will continue to blow cool air for 30 seconds before shutting down.

A thermal overload protector is built into the unit to prevent overheating
If the unit overheats it will shut down automatically.

As the unit senses the air being drawn into the unit and the fact that heat rises, the unit may switch off before all of the room is fully up to temperature.

CARE AND CLEANING

- The unit should be cleaned regularly.
- Isolate from the mains supply and allow the unit to cool. Wipe over with a damp cloth.
- Do not use detergents or abrasives.
- Do not scrape the surfaces with sharp hand tools.
- Use a vacuum cleaner to remove dust and fluff from the vents.

SAFETY WARNINGS

- This product is not a toy. It should not be used by children or infirm persons without supervision.
- The appliance must be fastened to a wall with the air outlet to the bottom. **DO NOT** mount the unit any other way.
- Isolate from the mains supply when not in use or when cleaning the unit.
- **DO NOT** operate the appliance with a damaged cord. If the supply cord is damaged it must be replaced to avoid any hazard.
- Parts of the heater casing may get hot when in use. **Do not** let bare skin touch any hot surface to avoid burns.
- **Do not** allow the unit to get wet.
- **Do not** use the heater in dusty environments or where flammable vapours are present.
- **Do not** place the heater near any other source of heat.
- **Do not** cover the heater. A fire may occur if the heater comes into contact with any flammable material (Curtains, Drapes, Bedding etc...) when in use.
- **Do not** use in the immediate vicinity of bathtubs, showers, wash basins or swimming pools.
- **Do not** use outdoors.
- **Do not** use this appliance for other than its intended purpose. This appliance is for interior use only.
- **Do not** attempt to repair, disassemble or modify the appliance in any way. There are no user-serviceable parts inside.
- **Do not** insert or allow to be inserted any foreign objects into the inlet or output openings as this may cause an electric shock, fire or damage to the unit.
- **Do not** use this heater with an external programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered.
- **Only use the autotimer while the unit is supervised.**

GUARANTEE & WARRANTY

This product is covered with a 12 month manufacturers warranty from the date of purchase against faulty workmanship and components.

Should you need to return the unit please call QUANTUM ECO-ELEC on 05602-045420 for a Returns Authority Number (RAN) and our full postal address for repairs.

TECHNICAL SPECIFICATION

Supply Voltage	220 - 240V
Power rating	13A MAX
Frequency	50Hz
Output Power	1250 or 2500 Watts
Timer Control	0.5 - 7.5 Hours
Remote Control Range	7 metres MAX
Remote power source	2 x AAA Batteries

QE©

QE-7050A ISS.1